



TimeClock 330/380 Wall Mounting Template

TOP

Note: Don't forget to leave room above the clock for phone and power cables.



You were provided 2 screws and 2 drywall anchors.
If mounting on drywall, you'll want to use both the anchors and the screws.
If mounting on wood, you'll only need the screws.

DIRECTIONS:

- Place this sheet on your wall where the clock will be mounted with this side facing you.
- Mark the location of your screws on the wall by poking holes through the two crosses located on this sheet.
- Drill your screws or anchors through the markings on your wall.
- Unscrew the screws enough so that the clock can hang on them without its rubber feet getting in the way. The screws should stick out of the wall approximately 1/4 of an inch.
- Mount your clock by placing it so the two screws match the two mounting holes on the back, then firmly press down until the clock clicks in place.
- Pull on the clock lightly to ensure it won't fall off the wall.

The card reader slot will be right here. Be sure to leave room above and below the clock so that cards may be swiped through.