

Factory Reseting the Plum Lightpad


In some rare cases it may be helpful to perform a Factory Reset on a Lightpad. This document covers the procedure. If you perform a Factory Reset on a Lightpad that has already been Provisioned, delete the Light from the app first. You can delete individual lights from the Lightpad settings or delete the entire room if resetting multiple Lightpads in the same room. If you are resetting all your Lightpads you can delete the entire House under the main settings menu.

Factory Reset

1. Pull the air-gap tab out until the Lightpad loses power.

2. Use a paper clip to press and hold the reset button. Re-engage the air-gap tab while continuing to hold down the reset button until the glow ring glows purple.





Reset button

Airgap Switch