

# Getting Started: Spark Nano 4.0

## 1. Charging the Spark Nano 4.0

You will need to charge the Spark Nano 4.0 for 6 hours prior to first use. Connect Mini-USB cable to an electric outlet, using the AC Adapter.

## 2. Viewing

You should have received an email from BrickHouse Security containing a link to the tracking portal, along with your user name and password.

## 3. Tracking Your Device

Place the Spark Nano 4.0 on your car dashboard; continue driving for 20-30 minutes to establish a connection to the BrickHouse GPS server.

**Note:** For a complete Spark Nano 4.0 manual, troubleshooting tips, and how-to videos, please go to <http://help.brickhousesecurity.com> and type Spark Nano 4.0 in the search box.

**For technical support contact 1-800-654-7966**

For Videos and Tutorials on the Spark Nano 4.0, go to <http://l.bhs.net/sn4-guide>.



- 1. Power Button
- 2. Charging Port
- 3. Panic Button
- 4. SIM Card Slot

- 5. GPS LED
- 6. GSM LED
- 7. Battery LED